



StarCamp


Octavia Air Klimatex



CS UK

NÁVOD K POUŽITÍ

MANUAL - INSTRUCTIONS



Všechna práva vyhrazena. Žádnou část tohoto vydání nelze bez předchozího písemného svolení společnosti Doréma Vorzelte GmbH zveřejňovat ani reprodukovat prostřednictvím tisku, kopírování, mikrofilmu ani jiným způsobem.

PŘEDMLUVA

Srdečně blahopřejeme k pořízení vašeho nového předstanu StarCamp. Děkujeme, že jste se rozhodli pro předstan StarCamp a přejeme vám příjemnou dovolenou.

Zaručujeme vám optimální komfort na dovolené s garantovanou životností evropské značky: Nenecháváme nic náhodě. Nejde koneckonců o nic méně důležitého než vaši dovolenou. V předstanech StarCamp poznáte prvotřídní kempingové zážitky.

Jedním z nejzajímavějších témat při kempování je stavba a skládání vašeho předstanu. Při žádné jiné příležitosti se mezi kempaři nesejde tak rychle tolik dobrovolníků jako u sestavování a skládání stanů. Jakmile hřmotně vybalíte tyče, už z okolních stanů vykouknou první zvědavé hlavy. Po prvním hlasitém klení se rovněž objeví první dobrovolníci, kteří vám budou chtít pomoci. Stačí ještě připravit pár nápojů a stavba stanu může začít. Rychle budete mít po ruce profiky, kteří přiříznou příliš dlouhé tyče, doplní chybějící staré součástky, vyvrtají otvory, roztrídí části stanu atd. Nejpozději před použitím první pilky na železo byste však měli začít být obezřetní.

Na následujících stránkách vám popíšeme, jak se můžete obejít bez pomoci zvenčí a systematicky, bez problémů, pohodlně a bezpečně postavit každý předstan ve dvou. S nezbytným klidem a beze stresu bude proces stavby stanu mnohem rychlejší a hladší.

V tomto návodu k použití najdete rozličné informace o svém předstanu. Obsahuje praktické tipy ohledně údržby, servisu a další užitečné poznatky. V tomto návodu k použití najdete samozřejmě také snadno srozumitelný návod k sestavení, který vám rovněž trochu zjednoduší stavbu předstanu.

Abychom vám mohli zaručit bezproblémovou dovolenou v kempu, doporučujeme vám si tento návod důkladně pročíst. Dále vám doporučujeme nový předstan jednou postavit na zkoušku, ještě než vyrazíte na dovolenou. V případě dotazů prosím kontaktujte svého specializovaného prodejce.

OBSAH

1.	PŘED KEMPOVÁNÍM.....	5
1.1	Úvod.....	5
1.2	Kontrola rozměrů.....	5
1.3	Standardní výbava.....	5
2.	TYČE / NAFUKOVACÍ VZDUCHOVÉ TRUBICE.....	6
2.1	Umístění ventilů.....	6
3.	STAVBA NAFUKOVACÍHO PŘEDSTANU.....	7
3.1	Podklad.....	7
3.2	Kedrová lišta.....	7
3.3	Příprava.....	7
3.4	Odstranění přední a boční stěny.....	7
3.5	Zasunutí předstanu do kedrové lišty.....	7
3.6	Tlak vzduchu.....	8
3.7	Doplňková aretace.....	8
3.8	Nafukovací tyče stříšky nad vchodem.....	8
3.9	Napnutí.....	9
3.10	Zip přední stěny.....	9
3.11	Přístavba (volitelná).....	10
4.	UNIKÁNÍ VZDUCHU.....	11
4.1	Netěsnící vzduchové trubice.....	12
5.	SLOŽENÍ PŘEDSTANU.....	13
6.	VĚTRÁNÍ.....	14
6.1	Větrací otvory.....	14
7.	ÚDRŽBA A ČIŠTĚNÍ.....	16
8.	PŮSOBENÍ SLUNCE.....	17
9.	OPRAVY.....	18
10.	SBALENÍ A SKLADOVÁNÍ.....	19
11.	SERVIS A ZÁRUKA.....	20

1. PŘED KEMPOVÁNÍM

1.1 Úvod

I přes skvělou kvalitu našich předstanů vždy doporučujeme před dovolenou předstan a jeho příslušenství důkladně zkontrolovat a připravit. V případě chybějící součástky touto kontrolou předejdete nepříjemným překvapením v místě dovolené.

1.2 Kontrola rozměrů

Společně se svým dodavatelem jste vybrali rozměr svého nového předstanu. V případě jakýchkoli pochybností prosím ještě jednou zkontrolujte obvodovou délku vašeho karavanu předtím, než nový předstan vyjmete z originálního obalu. **Použité produkty nelze vyměnit.**

1.3 Standardní výbava

V závislosti na sérii dodáváme předstany StarCamp spolu s kolíky, které jsou vhodné k použití na normálním povrchu. Speciální kolíky na písek, skály a zimní kempování jsou k dostání u vašeho dodavatele. Napínací gumy, které jsou součástí balení, zajišťují dokonalé napnutí za všech okolností.

Součástí balení je i clona proti větru.




TIP: Než odjedete na dovolenou, připevněte všechny napínací gumy na kotevní háky předstanu. Ušetříte tím spoustu času při sestavování.

2. TYČE / NAFUKOVACÍ VZDUCHOVÉ TRUBICE

V předstanu jsou 2 druhy vzduchových trubíc. Hlavní sloupy jsou „pevně“ vestavěné v kapsách na trubice. Střešní podpěry jsou u stanu přiloženy volně.

2.1 Umístění ventilů

Předstan Octavia Air je vybaven více ventily, které se nacházejí na vnější straně stanu.



3. SESTAVENÍ

NAFUKOVACÍHO PŘEDSTANU

3.1 Zaparkujte karavan na rovný povrch zcela horizontálně, abyste zajistili optimální napnutí svého předstanu.

3.2 Než zasunete předstan do kedrové lišty, musíte zkontrolovat, že na ní nejsou žádné ostré hrany. Případné nerovnosti je nutné vždy odstranit, abyste předešli poškození předstanu. Zkontrolujte také, zda se na součástkách kolem kedrové lišty nenacházejí zbytky tmelu.

3.3 Abyste předešli znečištění svého předstanu, doporučujeme použít plastovou fólii, na které můžete předstan vyrolovat. V případě potřeby vyčistěte i kedrovou lištu, abyste zabránili znečištění.

3.4 Po rozložení předstanu rozepte zipy, které drží přední a boční stěny. Po odstranění těchto stěn bude stavba předstanu o něco snazší.

3.5 Nyní můžete začít se zasouváním předstanu do kedrové lišty. Zasouvání bílého kedru by měly ideálně provádět dvě osoby, přičemž jedna má na starosti zasouvání a druhá správně navléknutí kedru do lišty. Vypínací body upevněte doleva a doprava ve stejné vzdálenosti od země.

3.6 U plně zasunutého nafukovacího předstanu stačí základní tyče nafouknout pomocí jednoho ventilu. **Všechny vzduchové trubice je třeba nafouknout tlakem 6 až 8 psi (0,5 až 0,6 bar).** Dejte přitom pozor na to, aby všechny černé speciální ventily na vnitřní straně byly otevřené. (Na ventilech jsou za tímto účelem připevněné značky). Tento předstan má speciální ventily, se kterými můžete nafouknout základní konstrukci jednak pomocí jednoho ventilu, jednak můžete v případě potřeby ventily i uzavřít a používat jednotlivé prvky stejně jako u systému s více ventily. To má značné výhody, pokud hledáte případné netěsnosti a pokud předstan používáte v kempu. U nafukování nezáleží na tom, se kterým ventilem začnete. Není to podstatné. Dejte prosím pozor na to, aby zbylé ventily na přední straně byly uzavřené.




3.7 Doplňkovou aretaci můžete následně upevnit na odpovídající místa. Na příslušných místech ve střeše jsou za tímto účelem duté lemy a suché zipy k upevnění sloupů.



TIP : Začněte stejně jako u jiných tyčí uprostřed stanu, abyste rychle mohli začít pracovat pohodlně vestoje.

3.8 Součástí balení jsou dvě nafukovací trubice, které zajistí další stabilitu stříšky nad vchodem.

3.9 Nyní začněte s napínáním nafukovacího předstanu pomocí napínacích gum a kolíků. Nejprve upevněte všechny napínací gumy na kotevní háky. Nyní umístěte kolíky do země, začněte s upevněním podlahy ve dvou rozích bočních stěn na straně karavanu, viz č. 1 a 2 na obrázku. Poté umístěte dva kolíky na oba přední rohy, č. 3 a 4. Přitom je nutné pečlivě dbát na to, aby stěny stály přesně v jedné rovině. Nyní můžete umístit zbývající kolíky, č. 5 a 6.



3.10 Zip přední stěny

Pokud jedna nebo obě trubice střešního štítu (trubice ze střední hlavní trubice směrem doprava a doleva ven) nejsou 100% upevněny/umístěny na správném místě, může se stát, že bude trubice pod silným tlakem a napětím na zaoblení zipu bude příliš velké. K tomu bohužel může dojít při zabalování a vybalování nebo přepravě stanu.

Nejedná se o vadu montáže nebo stanu.

Proto prosím vždy zkontrolujte usazení a pozici trubic. V případě potřeby je nutné je přizpůsobit a upravit. Důležité je rovněž přesné umístění 3 hlavních trubic (pravé, levé a střední). Nezapomeňte ani na průchody dopředu do stříšky nad vchodem a jejich upevnění ke cloně stříšky. I zde musíte zkontrolovat a případně přizpůsobit polohu.

3.11 Použití volitelné přístavby se zipovým systémem

Na levou nebo pravou stranu tohoto nafukovacího předstanu je možné připevnit přístavbu. Přístavbu připevněte k boku předstanu pomocí zipu. K tomu je potřeba nejprve sundat příslušnou boční stěnu.

1. Nyní nafoukněte hlavní trubici přístavby.
2. Poté nafoukněte střešní nosiče, které jsou součástí balení, a upevněte je mezi boční střešní nosiče předstanu a hlavní trubici přístavby.
3. Nyní můžete napnout stěny přístavby.



4. UNIKÁNÍ VZDUCHU

Nafukovací vzduchové trubice jsou vsazeny do šedého pláště, který je vybaven zipem. Jezdce zipů jsou zajištěny plastovou pojistkou (spojovačem kabelů). Zipy se NIKDY nesmí rozezpínat, pokud jsou vzduchové trubice nafouknuté. Lze je rozepnout pouze za účelem oprav. Po opravě musíte jezdcy VŽDY opět zajistit spojovačem kabelů. Zamezíte tím nechtěnému rozeznutí zipu.

Pokud u jednoho z nafukovacích sloupů klesá tlak, zkontrolujte nejprve, zda ventil správně sedí a je pevně zatočený. V případě úniku vzduchu je často správným řešením uvolnit a opět utáhnout ventil (viz obrázek 1-2-3).



Dávejte přitom pozor také na všechna těsnění a uzavření krytů ventilů.

4.1 Netěsnící vzduchové trubice


Jak je uvedeno v návodu k sestavení, je nejprve třeba zkontrolovat, zda je ventil pevně uzavřený. Pokud ze vzduchové trubice pomalu uniká vzduch, může být nejrychlejším řešením uvolnění a opětovné utažení ventilu.

Pokud vzduchová trubice netěsní, lze ji jednoduše opravit.

Doporučujeme opravnou sadu Doréma TEAR-AID typu B, kterou můžete zakoupit u našich specializovaných prodejců.

Opravná sada Doréma TEAR-AID typu B je obzvlášť vhodná na opravu PVC materiálů.


1. Sundejte z jezdce spojovač kabelů a rozepněte zip.
2. Poté sundejte průhlednou vzduchovou trubici a nafoukněte ji.
3. Přidržte vzduchovou trubici pod vodou a zjistěte, kudy uniká vzduch.
4. K utěsnění místa úniku použijte opravnou fólii ve správné velikosti. Přesně přitom dodržujte pokyny v návodu k použití sady TEAR-AID.
5. Nasadte vzduchovou trubici zpět do pláště. Ventil namontujte opět na správné místo. Zapněte zip a znovu zajistěte jezdce pomocí spojovače kabelů.



5. SLOŽENÍ PŘEDSTANU

Předstan skládejte jen v suchém stavu.

Sundejte vzduchovou trubici v oblasti střechy a otevřete ventily. Ventily jsou ukotveny na ochranném plášti a nemůžete je tedy ztratit. Poté ventily opět pevně zatočte a nechte je tak až do příštího sestavování stanu. Složte, příp. srolujte předstan tak, aby byly ventily pokud možno co nejdéle uvolněné a mohl z nich uniknout veškerý vzduch.



6. VĚTRACÍ OKNA

Při vypínání stanu vždy otevřete větrací okna. Kvůli velmi silné síťovině zpevněné sklolaminátem by se jinak mohla fólie svažovat. Pokud ve stanu delší dobu nebudete, měly by být okenní fólie vždy zavřené. Okenní fólie se přirozeně smršťují a při déle otevřených oknech se srazí. Může nějakou dobu trvat, než se fólie opět zcela roztáhne a okenice bude opět optimálně pasovat.

Proto byste měli i za hezkého počasí okenici v pravidelných intervalech na noc zavírat, aby se fólie roztáhla. Případně si můžete také pomoci teplem a fólii zahřát fénem, abyste ji mohli lépe roztáhnout.

6.1. Větrací otvory, nucené odvětrávání


Při kempování v přírodě vždy dochází ke kondenzaci vody, která se na různých látkách usazuje rozdílně. Vlhký vnitřní vzduch, vlhkost, která vzniká při pocení, rosa a jinovatka se usazují především na chladných a hladkých plochách. Při velmi vysoké vlhkosti vzduchu lze vlhkost pozorovat i na teplých plochách. I za deštivého počasí si můžeme všimnout, že polštáře, části oděvů i závěsy v předstanu jsou vlhké.

Abychom této vlhkosti předešli, existují větrací okna a nucené odvětrávání. **Nucené odvětrávání prosím nikdy nezavírejte.** Slouží k zajištění přívodu čerstvého vzduchu a odvodu případných plynů a kondenzované vody ven. Větrací otvory v bočních stěnách tomuto procesu značně napomáhají. Mají vliv i na klima v předstanu. Otevřená větrací okna přirozeně právě v létě zajišťují snesitelné klima v předstanu.

DĚŠŤ A VLHKOST

Díky speciálním švům a procesu sešívání je váš stan v podstatě nepromokavý. Vždy však myslíte na to, že se stále jedná o stan a v místech spojení dílů mohou vznikat otvory, kterými může dovnitř pronikat vlhkost. Vlhkost si přitom vždy najde svou cestu. Často se vlhkost objeví na zcela jiných místech uvnitř stanu než tam, kde si všimnete mokra.

V případě příliš malého napnutí kedru předstanu jím může vlhkost projít a dostat se tak dovnitř stanu. Někdy může vlhkost proniknout dovnitř i příliš velkým otvorem od jehly. Použitý materiál přize po prvních dnech používání přirozeně nabobtná a teprve rozvine svou tloušťku, aby tento otvor utěsnil. Se speciálními impregnacemi může tento proces trvat různě dlouhou dobu. Pokud jsou i po nějaké době v těchto otvorech stále patrné malé kapičky vody, je možné je dále ošetřit přípravkem na utěsnění švů. Toto ošetření doporučujeme zejména u syntetických materiálů.




7. ÚDRŽBA A ČIŠTĚNÍ

Po dovolené byste měli svůj stan vyčistit. Používejte zásadně čistou vlažnou vodu a jemný měkký hadřík.

V případě silného znečištění můžete většinu stanů čistit i vysokotlakým čističem. Nastavte však tlak na nízkou úroveň nebo dodržujte odpovídající odstup od materiálu. Na okenní fólie je nejlepší použít čistý bavlněný hadřík a prášek do pečiva. Můžete tak bezpečně a šetrně odstranit většinu nečistot.

Okenní fólie jsou velmi náchylné k poškození čistícími prostředky. Zbytky tenzidů rychle způsobí změnu zabarvení. Abyste odstranili malé trhlinky na okenních fóliích, můžete použít fén nebo horkovzdušné zařízení, dávejte však pozor na to, abyste nemířili příliš dlouho na jedno místo. Po nějaké době se tyto trhlinky však zcela přirozeně objeví znovu.

V závislosti na teplotě a tloušťce fólie to může trvat různě dlouhou dobu. U fólií používaných u oken předstanu nelze těmto trhlinkám zabránit a nejedná se o kvalitativní vadu.




8. PŮSOBENÍ SLUNCE

U všech našich produktů používáme pouze vysoce kvalitní materiály, které poskytují ochranu i proti UV záření. I naše nafukovací předstany z materiálu KlimaTex vám poskytují dokonalou ochranu. V závislosti na intenzitě vlivů počasí se však látky přesto opotřebovávají. Právě slunce se v současné době stalo významným faktorem.

Proto vám doporučujeme vybírat si i při kempování vždy stinné místo a nevystavovat stan permanentně slunečnímu záření. Při dlouhodobém kempování byste měli dávat pozor na uzavíratelná okna.


Téměř všechny naše zipy jsou zakryté. Snižuje se tak opotřebení vlivem počasí a zároveň jsou ještě více chráněny před proniknutím vody a znečištěním.



9. OPRAVY

Bohužel se vždy může stát, že některá část stanu bude vadná nebo že může dojít k jejímu poškození. Samozřejmě se v takovém případě můžete obrátit na nás a naše obchodní partnery, abychom záležitost kompetentně vyřešili. Myslete prosím na to, že každá „laciná oprava“ se vyplatí jen na chvíli. Vždy se může stát, že si na dovolené nejprve budete muset poradit svépomocí, abyste přečkali další dny. Opravy byste však vždy měli nechat provádět odborníky, a to co nejdříve od chvíle, kdy k poškození došlo. V naší nabídce příslušenství najdete speciální opravné sady A a B v závislosti na materiálu. Ve specializovaných prodejnách najdete nažehlovací látky, PVC lepidla, studené svary, nitě z tuby, nástroje na poutka atd. Tyto věci jistě můžete použít, abyste si vypomohli na dovolené. Myslete však na to, že následně je potřeba nechat problém správně vyřešit odborníka, který má k dispozici správné přístroje a materiál.

Obstarejte si vždy pár nejdůležitějších malých součástek, jako jsou jezdec zipů, příze, očka, jehly atd., abyste si na dovolené v případě problémů mohli poradit svépomocí.



10. SBALENÍ A SKLADOVÁNÍ

Předstan byste měli balit zásadně suchý a čistý. Existuje spousta různých názorů na to, jak stan správně a šetrně sbalit, zda byste ho měli srolovat nebo složit apod. Zde pro vás máme několik podstatných tipů:

- Okenní fólie vždy položte dovnitř.
- Střechu vždy použijte jako vnější obal spodní stranou směrem ven.
- Zipy se nesmí dostat do kontaktu s okenními fóliemi.
- Nerolujte do stanu žádné kamínky, lístky nebo trávu.
- Záclony mohou klidně zůstat vytažené jako ochrana okenních fólií.
- Stan a tyče/nafukovací tyče vždy balte zvlášť.
- Nepřibalujte ke stanu žádné ostré předměty.

Pokud budete dbát na tyto věci, budete mít ze svého stanu dlouho radost.

Nenechte se zmýlit „takzvanými“ odborníky a vždy používejte zdravý rozum, který je často nejlepší.

Pokud si někdy nebudete jistí a rádi byste si nechali odborně poradit, vaše dotazy jistě rádi zodpoví naši odborní obchodní partneři/specialisté.

Naše lokální partnery permanentně školíme v odborných znalostech a neustále pracujeme na vylepšeníh a ulehčeníh, která vám můžeme přinést.

Pokud by vaše otázka přesto zůstala nezodpovězena nebo pokud máte návrh na zlepšení, budeme vám rádi k dispozici i osobně. Jelikož se náš obor empiricky vyvíjí, i my žijeme z dobrých nápadů a zkušeností kempařů.

11. SERVIS A ZÁRUKA

11.1 Úvod

StarCamp se snaží dodávat co nejkvalitnější produkty. Naše předstany a sluneční střechy vyrábíme z materiálů nejvyšší kvality, které pečlivě zpracovávají zkušení specialisté a kontrolují speciálně vyškolení pracovníci oddělení kvality. Na všechny naše produkty se vztahuje dvouletá záruka. Všechny případně zjištěné nedostatky související s vadami materiálu nebo výroby zdarma opravíme.

11.2 Uplatnění záruky

Máte-li otázky k pořízeným produktům, obraťte se prosím na svého specializovaného prodejce, který bude řešit případy uplatnění záruky. Pokud chcete vznést nárok ze záruky, zašlete příslušný díl v čistém a suchém stavu. Znečištěné a mokré stany nemůže náš servisní personál a stroje zpracovat a vracejí se v nezměněném stavu zpět.

11.3 Záruka


Ve všech případech je to společnost StarCamp, kdo rozhoduje, zda máte nárok na záruční plnění. Škody vzniklé z důvodu nadměrného zatěžování, nesprávného používání nebo bouřky nejsou kryty zárukou. Případné cestovní a/nebo přepravní náklady nenahrazujeme. Společnost StarCamp si ve všech případech vyhrazuje právo na dodatečné vylepšení. Zkušený kempař ví, že následující jevy nelze považovat za vady a že nemají vliv na používání předstanu nebo sluneční střechy.

- zduření nití v plátně stanu;
- barevné odchytky jednotlivých pruhů plátna stanu;
- změny barev v důsledku vlivu počasí a okolního prostředí;
- světlé skvrny v PVC materiálu – jde o takzvané pigmentové skvrny, kde chybí barevný pigment. Materiál v těchto místech není netěsnící ani méně kvalitní;
- kondenzace vody, v extrémních případech až kapičky vody, především u švů v blízkosti tyčí;
- nerovnosti okenní fólie.

Po prvním postavení stanu je možné, že místa švů při prvním dešti propustí trochu vody.

Někdy může vlhkost proniknout dovnitř i příliš velkým otvorem od jehly. Použitý materiál přize po prvních dnech používání přirozeně nabobtná a teprve rozvine svou tloušťku, aby tento otvor utěsnil. Se speciálními impregnacemi může tento proces trvat různě dlouhou dobu. Pokud jsou i po nějaké době v těchto otvorech stále patrné malé kapičky vody, je možné je dále ošetřit speciálním sprejem. Toto ošetření doporučujeme zejména u syntetických materiálů.

Švy na vnitřní straně předstanu jsou vybaveny transparentním ochranným páskem.



All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any other means, without written permission from Dorema UK Ltd.

FOREWORD

Congratulations for purchasing a new StarCamp Air awning. We would like to thank you for choosing StarCamp and wish you lots of enjoyable camping holidays.

You are always assured of simplicity of erection along with guaranteed durability of a quality manufacturer: we don't leave anything to chance. After all this is your holiday. With StarCamp you can see the built in camping expertise. The best quality fabric, extra reinforced stress points, innovative in many ways and easy and quick to erect on every surface. Our continuing process of selecting the very best in raw materials, along with our commitment to modern technology and recruitment of experienced staff makes StarCamp stand out with lots of practical camping comforts. In practice we keep this promise into every detail. It's not by accident that StarCamp is the best sold Air awning in Europe, again and again satisfied customers choose this make that has more to offer for less money.

In this handbook you will find all sorts of important information about your Air awning. It's full of practical tips concerning the upkeep and service of your new Air awning. Of course we have included a step by step guide on how to erect your Air awning, as well as informing you of the various optional accessories to make your Air awning even more complete.

To prevent any problems we strongly advise you to read this handbook thoroughly before you start to erect your Air awning. We also strongly advise you to erect your Air awning at least once before you commence your holidays. If you have any questions or problems please don't hesitate to contact your supplying dealer.

INDEX

1.	BEFORE YOU GO CAMPING.....	25
1.1	Introduction.....	25
1.2	Checking your Airawning size.....	25
1.3	Standard equipment.....	25
2.	FRAME / INFLATABLE TUBES.....	26
3.	ERECTING YOUR AIR AWNING.....	26
3.1	Ground.....	26
3.2	Tunnel.....	26
3.3	Pitching.....	26
3.4	Inflate Airtubes.....	27
3.5	Pressure.....	27
3.6	Roof bars.....	27
3.7	Pegging points.....	28
3.8	Guy ropes.....	28
3.9	Annex (optional).....	29
4.	LEAKING AIR TUBES.....	30
5.	TAKING DOWN YOUR AIR AWNING.....	31
6.	DURING USE.....	32
7.	CARE OF AWNING.....	33
7.1	Resin stains.....	34
7.2	Tree leaves.....	34
7.3	Grease stains.....	34
7.4	Bird droppings.....	34
7.5	Mildew.....	35
8.	EXPOSURE TO UV RADIATION.....	35
9.	STORING YOUR AIR AWNING.....	36
10.	SERVICE AND WARRANTY.....	38

1. BEFORE YOU GO CAMPING

1.1 Introduction

Now that you own this beautiful StarCamp Air awning, it is very important to check and prepare everything before you go on holiday.

1.2 Checking your Air awning size

With the assistance of your dealer you will have chosen your correct awning size. If you have any doubts please measure your caravan again before you take the new awning out of it's original packing.

Please note that awnings that have been on a caravan can not be exchanged.

1.3 Standard equipment

StarCamp Air awnings are supplied with standard pegs which are suitable for normal camping. Special pegs designed for other types of ground conditions, such as sand or rocky grounds, are available from your local dealer. The standard ladder straps will ensure the correct tension is applied to the Air awning.



TIP: Before you go on holiday attach all ladder straps onto the anchor fittings of your awning. This will save a lot of time when erecting the Air awning.

2. FRAME / INFLATABLE TUBES

Your StarCamp Air Awning is supplied with two types of Air tubes. The main tubes, fitted into the sleeve on the inner side of the Air awning, and the separate roof support poles.

Octavia Air is equipped with 3 inflation valves, which are located at the outside of the front panel.

3. ERECTING YOUR AIR AWNING


3.1 You may wish to lay a plastic sheet on the ground to protect your awning. Unpack and spread the awning on the ground.

Before you start to insert the awning into the caravan rail, you first need to check the rail for any sharp edges. In order to prevent any damage from happening to the awning always remove any obstructions. Also check for any sealant that may remain inside the caravan rail.

3.2 After you have unfolded the awning, zip out all the removable panels. By removing those, sliding the awning through the caravan rail will become a lot easier.

3.3 You can easily erect the fully inflatable awning. Inflate it by using the supplied hand pump or the optional electric air pump. Select the correct end piece, place it on the hose and attach it to the valve. **Inflate the air tubes up to a pressure of between 6 to 8 Psi (= 0,5 – 0,6 bar).**


3.4 The base frame of the awning can be inflated by using one of the three valves, which are attached to the outside of the awning. It does not matter which valve you choose. Please make sure, both other valves are closed. Dorema recommends using the valve of the center upright to inflate the base frame. This quickly creates extra workspace, which makes it easier to erect. Make sure that the black valves - attached to the inside of the roof - are open when inflating. The markings are placed on the black valves. The black valves connect the main air hoses with each other by means of a light grey, thinner air hose. If necessary, you can also close the black valves and close the air hoses separately. This is especially useful when looking for a possible leak in the air frame.



3.5 The additional roof rails that are in the sewn-on tunnels in the roof and extra uprights can be inflated now and the uprights can be placed in the right position.

3.6 Two inflatable canopy bars are included for extra stability in the front canopy.

3.7 You are now ready for pegging the awning with the use of ladder straps and pegs. Always start at the corners. Start at the caravan side with points 1 and 2, then the corners 3 and 4 of the front. Work from the middle, points 5 and 6 to both corners. Now you can peg out the rest of the awning.



3.8 Tension on zipper of the front panel.

In case the air tube running from the center corner to either the left or right-hand corner is not completely in the correct position, it will cause too much tension. This air tube is attached to the corners by means of Velcro and if not 100% fixed in the correct position, the air tube comes under too much pressure, causing too much tension on the zipper. Therefore it is important to check this connection and adjust it if necessary.


It is also important to check if the short canopy stub air tube, located on the outside under the awning canopy, is exactly in the correct position.

The described situation is no production error and can be adjusted easily.

3.9 Optional annex with zip

This inflatable awning offers the opportunity of fitting an annex on either the left or right-hand side. Unzip the desired side wall to extend the awning with the annex.

1. First start to inflate the main air tube, the valve is situated on the outside of the annex.
2. Next inflate the supplied roof tube and place it between the side roof beam of the awning and the main tube of the annex.
3. The canvas of the annex can now be pegged out.



4. LEAKING AIR TUBES


As mentioned before in this instruction, first you need to make sure the valves are screwed on tightly enough (finger tight!). In case the air tube loses air slowly, unscrewing the valve and assembling it again is usually the simplest solution for the leakage. In case one of the air tubes really gets punctured it can be repaired in a simple way.



1. Remove the ty-rap from the slider and open the zip.
2. Remove the transparent air tube from the casing, fit the valve and inflate the tube with a pump.
3. Dip the tube under water and trace the leak.
4. Use the enclosed repair patch in order to close the leak.
5. Re-fit the air tube back into the casing, assemble the valve on the correct position, close the zip and **ALWAYS** secure the slider of the zip with a ty-rap. Your StarCamp dealer can also supply all replacement parts. In case you do not have a repair patch available, a Dorema TEAR-AID repair patch type B can also be used. Type B is especially suitable for all PVC materials. Such a repair set is also available at your local dealer.

5. TAKING DOWN YOUR AIR AWNING


It is recommended to take the Air awning down when it is completely dry. Remove the roof bar and unscrew all the valves. The valves are secured to the sewn on casing in order to prevent loss. Only screw the valves back on when the awning is erected again. Fold or roll up the awning in such a way that the valves are kept free as long as possible in order to allow the air to escape.



6. DURING USE

Air Awnings containing a high proportion of synthetic materials are sometimes affected by condensation. This should not be confused with leakage and can normally be cured by ensuring that adequate ventilation is available by making full use of the awnings ventilation or by leaving doorways slightly unzipped whenever possible.

Avoid touching the inside surface of the awning when raining. Any leakage should be treated with a suitable reproofing spray. Don't pitch your awning under trees but make use of natural windbreaks like hedges and walls. Face the awning door away from the prevailing wind. When the awning has been taken down wet, it is vital to ensure the awning fabric is dried out completely within a maximum of twenty-four hours. Do not cook in the awning or use naked flames. Read and understand the fire precautions label sewn into the inside of the awning.



7. CARE OF AWNING

Awning fabrics can be weakened by prolonged exposure to sunlight. Under normal holiday use your awning will give long service but used for extended periods in strong sunlight will soon cause deterioration. In those cases it would be wise to use a site as shaded as possible. UV degradation is not covered under the awnings warranty. The warranty does not cover awnings for permanent or seasonal site use. This is the ideal awning for short breaks.

Awnings are best stored loosely packaged and ensure it is totally dry before packing away. Store in a well ventilated dry place. A wet/damp awning will develop mildew surprisingly quickly. Dirty awnings can be washed using clean water and a soft brush. Do not scrub and never use detergent.

Look after your awning and it will look after you. Have any damage repaired at the first opportunity. Zips should be treated with care, use two hands to close and open and do not tread on them. Never force a zip. We strongly recommend that you carry a comprehensive spares kit including silicone waterproof spray and spare guy ropes and pegs for extreme weather. We provide a small repair kit to cope with minor accidents and problems. If the patch is sewn onto the awning you will have to seal the stitch holes with seam seal.

If you have any queries relating to your Air awning, or its warranty, then please contact your supplying dealer.

During your holiday your awning can get pretty dirty. This can be caused by a number of reasons of course. For instance, when you have experienced a long period of dry weather, a lot of dust can be found on top of your awning. By regularly dusting the canvas with a dry brush you will prevent black runs from appearing after the first shower of rain. You can already start with some of the maintenance during the last day of your holiday. When the weather permits, you can start to clean the mud walls of the awning with lukewarm water and leave it to dry. After you eventually dismantle the awning, you can clean the ground sheet, draught skirt and pegs and dry them.

For cleaning the awning you should, regardless of the type of material, always use clean water (approx. 30 degrees) and a sponge or soft brush.

Do not use detergent at any time as this can seriously damage the waterproof qualities of the canvas. We also strongly advise you not to purchase any of the cleaning detergents for canvases which are available at your camping stores, as these damage the waterproofing qualities of the canvas.

The seams on the inside of the awning are provided with a transparent, protective tape.

Re-impregnating the canvas afterwards will often not deliver the desired effect. Not all stains can be removed just with clean water. Below this we will explain how specific stains can be removed for the greater part.



TIP: It is preferred not to camp underneath trees that drip resin; resin damages the canvas.

7.1 Resin stains

Make sure all resin stains are cured sufficiently first. When the resin is cured sufficiently, it can easily be ground to powder. Carefully remove any remains with a spoon or knife and make sure you do not damage the fabric.

7.2 Tree leaves

Tree leaves pigment can come off tree leaves leaving stains on the canvas that are difficult to remove. Especially moist leaves tend to stick to the fabric. So please be alert and remove leaves as soon as possible.

7.3 Grease stains

Dab butter, gravy or oil stains as soon as possible with kitchen paper. Any remains can be removed later with the help of an iron (coolest position) and kitchen paper. Put the paper on the concerning spot and warm the paper with the iron so that the grease is absorbed by the paper.

7.4 Bird droppings

There is no standard method for cleaning this type of stain. The best thing to do is to scrape or wipe the remains from the canvas as soon as possible. Then clean the spot with lots of lukewarm water and leave any remaining stains. Normally these remains will automatically disappear eventually.

7.5 Mildew

Mildew caused by moist weather can be recognized by small brown spots which are found inside the canvas. In most cases this happens because a moist awning has been packed too long. Regardless of the type of the material the awning is made from, you always need to make sure that when an awning is packed wet, it is hung to dry within twenty-four hours and has the opportunity to dry properly.

Mildew can also occur when the canvas is used during a long period of time in a moist environment. During the production of most awnings synthetic fibers are used which are coated.

With most fabrics this coating is on the outside of the canvas only, because of this, this material will cause almost no condensation because the fibers on the inside of the awning will absorb some of the moisture. In this damp condition mildew can start to settle, which will then lead to the brown spots as mentioned before. Most of the condensation is caused by large differences in temperature. This occurs specifically during spring and autumn. When the humidity in the awning is high for a long period of time, brown spots can appear on the inside of the awning. Permanent site campers will therefore experience mildew quicker than people who camp only a few weeks during the summertime. Otherwise, the mildew does not effect the quality of the roof material and has also no negative influence on the durability of the awning. By using a ground sheet with good sealing qualities condensation built up can be reduced dramatically. In case you use an awning carpet, it is advisable to use some foil underneath the carpet to avoid condensation from building up. Of course it is very important that there is enough ventilation.

8. EXPOSURE TO UV RADIATION

Our inflatable tent line produced of KlimaTex material provides some protection against UV. Despite all the precautions, these materials will age when used under the influence of UV. Therefore, we recommend choosing a shady camping spot for your vacation. Most zippers are covered, which prevents premature aging and pollution.

9. STORING YOUR AIR AWNING

After you have cleaned the Air awning completely, it is very important to store the canvas in a dry place.



TIP: Prevent canvas and window material from getting into contact with materials which contain rubber or PVC such as: boots, cables, doormats, plastic covers or something similar. Because of softeners being used in numerous materials brown spots can start to appear inside the canvas and window material which are impossible to remove.

Window material

The window material used in Air awnings, is made from relatively soft materials. This means that the otherwise very smooth window material, by folding it between the other materials, can copy the relief of zips, canvas and mud walls into the window material. When you store the Air awning after you have camped, we would like to advise you to lay out all the panels, which have the window material, as flat as possible and not roll them tightly. The chance of slight marks or imprints been left on the window material will be minimized.


Regarding the window material we also would like to mention that every new Air awning, which comes straight out of the packing, is likely to have some creases and marks from been packed. When the Air awning is erected and tightly tensioned in warm weather conditions for a longer period of time, these marks will largely disappear. However window material is very complex material and therefore minor imperfections will need to be accepted as this is inherent to the material.

If your awning is stored at the end of the season, it is important that the awning is in a clean and dry condition.

Window Decals always lay inside

- Always fold the window material on the inside
- Do not fold or roll the canvas to tight
- Always store the roof with the coated side out
- Avoid contact with zippers and window material
- Do not pack stones, leaves or grass clippings
- Window blinds can serve as protection for the window film
- Avoid packing sharp objects

If you follow this advice you are assured of a long enjoyment of your awning.



10. SERVICE AND WARRANTY

10.1 Introduction

StarCamp tries to provide you with a durable product. Our awnings are made from the best quality materials, and are carefully produced by experienced craftsmen and checked by specially trained quality control employees.

All our products have a twelve months warranty. Any faults which relate to material or production errors will be repaired free of charge.

10.2 Dealing with warranty claims


In case you have any questions relating the product you have purchased, you should immediately contact your supplying dealer. Your dealer will take care of any possible warranty claim. If you wish to make a claim under warranty, please make sure that the item concerned is returned in a clear and dry condition. Soiled and wet awnings are impossible to handle by our service staff and sewing machines. Any awnings received in this condition will be returned untreated.

10.3 Warranty

In all cases StarCamp will decide whether a claim is considered warranty. Damage caused by excessive tensioning, storm damage or misuse can not be claimed under warranty. Any travel and/or transport costs made will not be compensated.

The experienced camper knows that the phenomena as stated below can not be considered faulty and have no negative effect on the solidity of the awning.

- Thread thickening in the material.
- Colour changes on different panels.
- Colour changes due to the weather or the environment.
- Light points in the PVC. These so-called pigment stains are not unusual and occur when the pigment that gives the colour is missing. This certainly does not indicate that the material with these spots will start leaking or have a lesser quality of material.
- Condensation, in extreme cases it will even drip, especially in the seams around the frame.
- Unevenness' in the window material. When the awning is erected for the first time, it is possible that water could penetrate through the seams during the first shower of rain. Once the thread has been wet it will start to swell, this will close the stitching. In most cases this problem will no longer occur during the next shower of rain.
- Most of the seams at the inside of the awning are covered by a protective transparent tape.



Doréma Rekreatie B.V.

Havenstraat 43 - 45
7005 AG Doetinchem
info@dorema.nl
www.dorema.nl

Dorema UK Ltd.

Pioneer Way, Castleford
West Yorkshire, WF10 5QU
info@dorema.co.uk
www.dorema.co.uk

Doréma Vorzelte GmbH

Kaiserswerther Straße 115
40880 Ratingen - Düsseldorf
info@dorema.de
www.dorema.de



092019